PCMT-01-PC Maintenance

This section includes information about tasks you can perform to help ensure the trouble-free operation of your PC, and to ease the recovery of important information on your PC should problems arise in the future.

Creating Data Backup Discs

- You can use the CD or DVD burning software included on your PC to create backup discs
 of important information including personal files, e-mail messages, and Web site
 bookmarks.
- When writing data to a backup disc, you should use software that includes write verification functionality. This verification feature compares the data on your hard disk drive with the data copied to the disc to ensure it is an exact copy. Depending on your disc burning software, you may need to manually enable this feature.

Creating System Recovery Discs

- This is a one-time step that you should perform while your PC is working properly. If you
 later encounter problems with your PC, you can restore it to its original configuration
 using the System Recovery discs that you create.
- Before creating recovery discs, read "System Recovery Overview", and then create the discs as described in "Creating System Recovery Discs".

Removing Unused Programs

- 1. Click Start, and then click Control Panel.
- 2. Double-click Add or Remove Programs. The Add or Remove Programs window opens.
- 3. Select the program you want to remove, and click the Change/Remove button
- 4. Follow the onscreen instructions
- ♦ Some programs have their own uninstall features. If you cannot uninstall a program from the Control Panel, try using the program to uninstall.

Running the Disk Clean-up Program

The Disk Clean-up program frees up space on your hard disk drive by removing temporary and unused files (including Temporary Internet Files and files in the Recycle Bin).

Running Disk Clean-up manually

- 1. Click Start, All Programs, Accessories, System Tools, and then click Disk Clean-up.
- Choose the files to delete by placing a check mark in the check box next to the file types listed
- 3. Click **OK**, and then click Yes to finish deleting the selected files

Scheduling Disk Clean-up to run automatically

- 1. Click **Start**, and then **Run**, and type the following into the open field: cleanmgr /sageset:100
- 2. Select the types of files that you want removed (for example, temporary files, Temporary Internet Files, and the files in the Recycle Bin).
- 3. Click **OK** to save the settings
- 4. Click Start, All Programs, Accessories, System Tools, and then click Scheduled Tasks
- 5. Double-click Add Scheduled Task and then click Next
- 6. Select Disk Clean-up from the application list and then click Next
- 7. Accept the default task name or type a name for the task, select when the task is performed, and click Next
- 8. Select the time and reoccurrence (if available), and click Next. Disk clean-up may take a long time, so select a time when the PC is on but not in use
- 9. Enter your login name and password and click Next
- 10. Select Open advanced properties for this task when I click Finish and click Finish.
- 11. In the Run field of the Disk Clean-up window add /sagerun:100 at the end of the path. For example: C:\WINDOWS\system32\cleanmgr.exe /sagerun:100
- 12. Click OK and, if prompted, verify your password

Running the Disk Defragmenter Program

- When Windows stores files on your hard disk drive, it often divides them into multiple pieces (or fragments) so they fit into available space on the drive
- When you attempt to open a fragmented file, it must be retrieved from more than one place, so the process takes more time.
- The Disk Defragmenter program groups the fragmented files together on your hard disk drive to improve PC performance.
- This does not affect the location of files and folders on your PC

Process

- 1. Open the **Windows Task Manager** by pressing the Ctrl key, the Alt key, and the Delete key at the same time
- 2. On the **Applications tab**, select all the programs that are listed, and then click **End Task**. Close the Task Manager
- Click Start, choose All Programs, Accessories, System Tools, and then click Disk Defragmenter
- 4. In the Volume column, select the hard disk drive you want to defragment, and then click Defragment

If Disk Defragmenter repeatedly starts, a hidden background program is still accessing the hard disk drive. Restart the PC in Safe Mode and run the Disk Defragmenter program again

- 1. Click Start, Turn Off Computer, and then Restart
- 2. Press the **F8 key** as soon as the first logo screen appears
- 3. On the Windows Advanced Options menu, use the arrow keys to select **Safe Mode** and press the Enter key
- 4. Press the Enter key again to select the operating system

- 5. Log on to Windows. When the Desktop message appears, click Yes to continue in Safe Mode
- 6. After Windows starts, use the previous procedure to run the Disk Defragmenter program

Checking for Hard Disk Drive Errors

- Perform the following procedure to check the integrity of the hard disk drive in Windows XP. Close all open programs before beginning the disk check.
- 1. Click Start, and then click My Computer
- 2. In the window that opens, right-click the hard disk drive that you want to check, and click **Properties**.
- 3. In the Properties window, click the Tools tab.
- 4. Under Error-checking, click Check Now.
- 5. If desired, click the check box next to Automatically fix file system errors and Scan for and attempt recovery of bad sectors
- 6. Click Start. If prompted to restart, click Yes to restart the PC

Recommended Maintenance Schedule

Daily	Weekly	Monthly	Quarterly (seasonally)
 Manage e-mail Delete e-mail from unknown sources. Do not open untrusted attachments. File e-mail. 	Protect against viruses, adware, and spyware Update definition files or schedule a weekly automatic update. Run a full virus, adware, and spyware scan or schedule a weekly automatic scan.	Use Windows Update Check for updates or schedule a monthly automatic update. (See the Getting Started Guide for details.)	Set new passwords (See the Getting Started Guide for details.)
	Optimize performance Run Disk Cleanup. (See "Running the Disk Cleanup Program" on page 1.) Check for disk errors. (See "Checking for Hard Disk Drive Errors" on page 2.) Run Disk Defragmenter.	Review the Start menu Set to launch only needed applications.	Clean the PC, monitor, keyboard, and mouse • For detailed cleaning instructions, go to http://www.hp.com/support select your country/region and language, search on your PC model number, and then search on the keyword cleaning.

Defragm page 2.)	nning the Disk enter Program" our browser	Clean up the desktop
Delete coDelete coDelete hi		 Delete or uninstall unneeded icons and applications. (See "Removing Unused Programs" on page 1.)
• This, and tasks, can the Disk (See "Rui	Recycle Bin I other cleanup In be performed with Cleanup program. Inning the Disk Program" on	 Maintain overall condition Check cleanliness. Make sure ventilation is unobstructed. Secure all connections and cabling.
or DVD	ng Data Backup	Create a Restore Point (See "Microsoft System Restore" on page 16.)

Questions

- 1. Write Down in few word what you understand PC Maintenance?
- 2. Write Down step of Scheduling Disk Clean-up to run automatically (MID-03M)
- 3. Write Down step of Removing Unused Programs ? (MID-03M)
- 4. Explain Disk Defragmenter Program in your word with step? (MID-03M)
- 5. Explain What is Creating Data Backup Discs (MID-05M)
- 6. Checking for Hard Disk Drive Errors (MID-05M)
- 7. Explain Recommended Maintenance Schedule (Daily bases , Weekly bases , Monthly bases , Quarterly bases (seasonally)





Join Us on Telegram @SOU BCA